



NEW ENGLAND RADON, LTD.
11A Industrial Way, Unit 3
Salem, New Hampshire 03079
(603) 893-4260 0 FAX (603) 893-8163
E-Mail: ner@choiceonemail.com
Website: www.newenglandradon.com

**WATER SAMPLING INSTRUCTIONS FOR
RADON WATER ANALYSIS**

IMPORTANT: Take water sample when it can be mailed immediately after taking the sample.

1. Run cold water to be sampled for at least **20 minutes**
2. After running water for 20 minutes, shut off and remove aerator if faucet has one.
3. Turn faucet on softly and fill glass vial until it overflows.
4. Screw cap on tightly.
5. Make sure there are ***no air bubbles*** in the vial by turning it upside down. If air bubbles are present, empty the vial and try again.
6. Be sure to indicate the date and time sample are taken.
7. Place the vial into bubble pack. Insert indie the mailer and seal the box.
8. Mail/deliver the sample as rapidly as you can.

* We recommend running an idle well at least overnight, then stop running and rest well for a few hours to be sure you are checking the water that will be in use.

**PLEASE PRINT LEGIBLY IN THE SPACES PROVIDED BEELOW. REPORT WILL BE MAILED TO THE ADDRESS BELOW.
SAMPLE CANNOT BE PROCESSED UNLESS COMPLETE INFORMATION IS PROVIDED.**

COMPANY NAME: _____ Maida Services, Inc. _____ BOTTLE # _____

NAME: _____

ADDRESS: _____

CITY: _____ STATE: _____ ZIP: _____

SAMPLING LOCATION: _____ By: _____

PHONE: _____ FAX: _____

DATE TAKEN: _____ TIME: _____

VA ___ FHA MIN ___ FHA MAX ___ STD ___ BACT ___ OTHER _____